## *Volatility Statement for the SR620*

The SR620 contains various types of memories, as listed below:

**Non-Volatile Memory:**

64 KB x 8 UVEPROM       Not user modifiable;
Contains instrument's firmware (and the factory
calibration bytes)

**Volatile Memory:**

32KB x 8  SRAM       user modifiable; used for last operation/user settings.
<u>To clear:</u>
Depress the RESET key while powering ON the unit.
Or, remove the back-up lithium battery

Please feel free to contact SRS should you have any further questions.