



Stanford Research Systems, Inc.
1290 C Reamwood Avenue, Sunnyvale, CA 94089, U.S.A.
Phone: 408-744-9040 FAX: 408-744-9049
Email: janied@thinkSRS.com .. Website: www.thinkSRS.com

Oct. 30, 2019

Volatility Statement for PRS10

The PRS10 contains various types of memories, as listed below:

Non-Volatile Memory:

512 Bytes EEPROM	User modifiable; Contains instrument's settings <u>To clear:</u> Send command "RC1"
20 kB EPROM	Not user modifiable Contains instrument firmware

Volatile Memory:

768 Bytes SRAM	User modifiable Used for operation/user settings. <u>To clear:</u> Send command "RS1"
----------------	--

Please feel free to contact SRS should you have any further questions.

Janie Du
Sales & Marketing